



FOR ALL SIDs AFTER DEPARTURE CLIMB INITIALLY TO FL55 OR AS CLEARED BY ATC.

- ESDEM 1A : RWY 28** : Climb straight ahead until 5D(DPN). Turn left to establish R-048 (CHI) to CHHILERKI VOR Then establish R-266 (CHI) to ESDEM VOR (114.0 LKA).
- DIPAS 1A : RWY 28** : Climb straight ahead until 5D(DPN). Turn left to establish R-048 (CHI) to CHHILERKI VOR Then establish R-225 (CHI) to DIPAS.
- ASOVO 1A : RWY 28** : Climb straight ahead until 5D(DPN). Turn left to establish R-048 (CHI) to CHHILERKI VOR DME(116.8 CHI). Then establish R-225 (CHI) to DIPAS/ASOVO.
- BADAT 1A : RWY 28** : Climb straight ahead until 5D(DPN). Turn left to establish R-048 (CHI) to CHHILERKI VOR. Then establish R-246 (CHI) to BADAT.
- ESDEM 1C : RWY 27** : Climb straight ahead until 5D(DPN). Turn left to establish R-051 (CHI) to CHHILERKI VOR. Then establish R-266 (CHI) to ESDEM VOR (114.0 LKA).
- DIPAS 1C : RWY 27** : Climb straight ahead until 5D(DPN). Turn left to establish R-051 (CHI) to CHHILERKI VOR. Then establish R-225 (CHI) to DIPAS.
- ASOVO 1C : RWY 27** : Climb straight ahead until 5D(DPN). Turn left to establish R-051 (CHI) to CHHILERKI VORDME(116.8 CHI). Then establish R-225 (CHI) to DIPAS/ASOVO.
- BADAT 1C : RWY 27** : Climb straight ahead until 5D(DPN). Turn left to establish R-051 (CHI) to CHHILERKI VOR. Then establish R-246 (CHI) to BADAT.
- ASOVO 1E, DIPAS 1E : RWY 28** : Climb straight ahead until 5D(DPN). Turn left track 175°M to RUTAG. Crossing R-240(DPN) turn right to establish R-228 (DPN) to DIPAS/ASOVO.
- ASOVO 1F, DIPAS 1F : RWY 27** : Climb straight ahead until 5D(DPN). Turn left track 183°M to RUTAG. Crossing R-240(DPN) turn right to establish R-228 (DPN) to DIPAS/ASOVO.