



FOR ALL SIDs AFTER DEPARTURE CLIMB INITIALLY FL55 OR AS CLEARED BY ATC.

PROCEDURE UPTO CHHILERKI VOR :

1. RWY 10 : Turn right before LO(303 PL). Track 210°M to DOLBY. Crossing R-152 (DPN) turn right to intercept R-082 (CHI) to CHHILERKI VOR DME (116.8 CHI).
2. RWY 09 : Climb straight ahead until 3D(DPN). Turn right track 210°M to DOLBY. Crossing R-152 (DPN) turn right to intercept R-082 (CHI) to CHHILERKI VOR DME (116.8 CHI).

PROCEDURE AFTER CHHILERKI VOR :

1. ESDEM 1B/1D : Establish R-266 (CHI) to LKA VOR.
2. DIPAS 1B/1D : Establish R-225 (CHI) to DIPAS.
3. ASOVO 1B/1D : Establish R-225 (CHI) to DIPAS/ASOVO
4. BADAT 1B/1D : Establish R-246 (CHI) to BADAT.

ASOVO 1G: RWY 10 : Turn right before LO(303 PL). Track 210°M to DOLBY. Crossing R-152 turn right to establish R-082 (CHI) to LITOP. Then turn left to establish R-228 (DPN) to ASOVO

DIPAS 1G: RWY 10 : Turn right before LO(303 PL). Track 210°M to DOLBY. Crossing R-152 turn right to establish R-082 (CHI) to LITOP. Then turn left to establish R-228 (DPN) to DIPAS.

ASOVO 1H: RWY 09 : Climb straight ahead until 3D(DPN). Turn right track 210°M to DOLBY. Crossing R-152 turn right to establish R-082 (CHI) to LITOP. Then turn left to establish R-228 (DPN) to ASOVO

DIPAS 1H : RWY 09 : Climb straight ahead until 3D(DPN). Turn right track 210°M to DOLBY. Crossing R-152 turn right to establish R-082 (CHI) to LITOP. Then turn left to establish R-228 (DPN) to DIPAS.